

# INSTRUCTIONS FOR USE


## Catchmaster 72Max



# APPLICATION

## 1. Unpacking


Carefully open the packaging and remove the adhesive traps.



1.

## 2. Folding


Fold the trap along the lines.



2.

## 3. Activate

Remove the protective sheet from the trap's adhesive surface.




3.

## 4. Choice of location

Choose areas where you have often observed mice or insects. Some examples of good locations include:


- Near walls and skirting boards
- Under furniture and appliances
- In cupboards and pantries



4.

## 5. Place the trap

Position the trap flat or folded in the chosen location along the wall, ensuring it is easily accessible to mice and rats.



5.

## 6. Use of bait (optional)

A bait can be applied onto the glueboard to attract mice. Suitable baits consist of fatty foods such as peanut butter or chocolate spread. Apply a small amount of the preferred bait onto the glue.

## 7. Regular checks

Check traps regularly, at least once a week, to detect the presence of mice or insects caught.

## 8. Replacing traps

Replace traps as soon as they are full or when their adhesive power diminishes.

### Important:

Keep the area as dust-free as possible, as the adhesive strength of the traps may decrease more quickly.

## SAFETY INSTRUCTIONS

- Avoid contact of the adhesive surface with the skin and other sensitive surfaces.
- Keep out of the reach of children and pets.

## WASTE DISPOSAL

Dispose of used traps and their contents in accordance with local waste disposal regulations.



**kæferling**

B2B Pest  
Control Shop

**kæferling**  
Pro